



Guida alla Configurazione Connettività FUTURE (OF) su Draytek 2962

1. Cablaggio della connettività

Procedere in primis con il corretto cablaggio con WAN nella porta RJ45 del DrayTek e successivamente il cavo di alimentazione;

2. General Setup

Accedere al Draytek 2962 all'IP 192.168.1.1 con parametri username: admin; password: admin

(Procedere con il cambio password a seguito di primo accesso e prima configurazione)

Index	Enable	Physical Mode/Type	Bandwidth(Kbps) DownLink/UpLink	Latency	Jitter	Pkt.Loss	Active Mode	Load Balance
WAN1	☒	Ethernet/Auto negotiation / P1	- / -	-	-	-	Always On	☒
WAN2	☒	Ethernet/Auto negotiation / P2	- / -	-	-	-	Always On	☒

Load Balance Setup: Advanced

Mode: IP Based

Line Speed: Auto Detect

Load Balance Weights: Bandwidth-Based

Note: Latency, jitter, and packet-loss require setting Link Condition Detection in each WAN setting page.

OK Cancel

Andare nella sezione WAN→General Setup, e procedere aprendo l'interfaccia della WAN1;

WAN 1

Enable: ☒

Display Name:

Physical Mode: VDSL2

DSL Mode: Auto

DSL Modem Code: Default

Line Speed: DownLink: 0 Mbps, UpLink: 0 Mbps

Link Condition Detection: Mode: Ping Detect

Primary Ping IP: 8.8.8.8

Secondary Ping IP: 1.1.1.1

Ping Interval: 1 Seconds(s)

Active Mode: Always On

VLAN Tag insertion: Customer (TPID 0x8100) Service (TPID 0x8100)

ADSL: Disable

Tag value: 0 Priority: 0

VDSL2: Disable

Tag value: 0 Priority: 0

Note:

- The line speed setting of WAN interface is available only when According to Line Speed is selected as the Load Balance Mode.
- In DSL auto mode, the router will reboot automatically while switching between VDSL2 and ADSL lines.
- Customer and service tag are used for different network environments. Customer tag is required for most ISPs while Service tag is required when ISP needs QinQ packets.

OK Cancel



Guida alla Configurazione Connettività FUTURE (OF) su Draytek 2962

Compilare il form che vi si presenta in questo modo, ponendo attenzione ai campi in giallo, quindi, procedere inserendo il Ping Detect, infine procedere con OK e se viene chiesto il reboot non è necessario farlo nell'immediato ma lo faremo dopo;

3. Internet Access

Andare nella sezione WAN→Internet Access, e procedere aprendo il Details Page della WAN1;

WAN >> Internet Access

Note:

VPN feature may be affected when the value of MTU is changed, please also check your value of VPN MSS in [VPN and Remote Access >> PPP General Setup](#) or [VPN and Remote Access >> IPsec General Setup](#) page.

We recommend to put the same decreased value on VPN MSS. For example, reducing the MTU from 1500 -> 1400, then it will need to reduce 100 from MSS value.



Guida alla Configurazione Connettività FUTURE (OF) su Draytek 2962

Compilare il form che vi si presenta in questo modo, ponendo sempre attenzione ai campi in giallo, quindi assicurarsi di essere nella sezione per il PPPoE e aver messo la spunta su Enable, impostare come username e password: openfiber, e settare correttamente Ping Detect e MTU con i valori in immagine, infine procedere dando l'OK e adesso procedere con il reboot del DrayTek.

Una volta settato il tutto attendere qualche minuto che la PPPoE salga correttamente, e la configurazione si può ritenere conclusa.