



Guida alla Configurazione connettività FUTURE (OF) su Draytek 2765/2865/2927

1. Cablaggio connettività

Procedere in primis con il corretto cablaggio con WAN nella porta RJ45 del DrayTek e successivamente il cavo di alimentazione;

2. General setup

Accedere al Draytek all'IP 192.168.1.1 con parametri username: admin; password: admin

(Procedere con il cambio password a seguito di primo accesso e prima configurazione)

DrayTek Vigor2865 Series

Auto Logout IP6

Dashboard
Wizards
Online Status

Search Menu

WAN
General Setup
Internet Access
Multi-PVC/VLAN
WAN Budget
LAN
Hotspot Web Portal
Routing
NAT
Hardware Acceleration
Firewall
User Management
Objects Setting
CSM
Bandwidth Management
Applications
VPN and Remote Access
Certificate Management
USB Application
System Maintenance
Diagnostics

WAN >> General Setup

Index	Enable	Physical Mode/Type	Bandwidth(Kbps) DownLink/UpLink	Latency	Jitter	Pkt.Loss	Active Mode	Load Balance
WAN1	☒	VDSL2/-	-/-	-	-	-	Always On	☒
WAN2	☒	Ethernet/Auto negotiation	-/-	-	-	-	Always On	☒
WAN5	☒	USB/-	-/-	-	-	-	Always On	☒
WAN6	☒	USB/-	-/-	-	-	-	Always On	☒

Load Balance Setup Advanced

Mode IP Based

Line Speed Auto Detect

Load Balance Weights Bandwidth-Based

Note:
1. Latency,jitter and packet-loss require setting Link Condition Detection in each WAN setting page.
2. Hide WAN3/WAN4 if the router does not support wireless WAN or no wireless device.
3. When Physical Mode/Type of WAN2 is not Ethernet or WAN2 is disabled, P6 port will be used as LAN.

OK Cancel

Andare nella sezione WAN→General Setup, e procedere aprendo l'interfaccia della WAN1;

WAN >> General Setup

WAN 1

Enable: Yes

Display Name: rtth_of

Physical Mode: VDSL2

DSL Mode: Auto

DSL Modem Code: Default

Line Speed: 0 Mbps

DownLink: 0 Mbps

UpLink: 0 Mbps

Link Condition Detection Mode: Ping Detect

Primary Ping IP: 8.8.8.8

Secondary Ping IP: 1.1.1.1

Ping Interval: 1 Seconds(s)

Active Mode: Always On

VLAN Tag insertion: Customer (TPID 0x8100) Service (TPID 0x8100)

ADSL: Disable

Tag value: 0 Priority: 0

VDSL2: Disable

Tag value: 0 Priority: 0

Note:
1. The line speed setting of WAN interface is available only when According to Line Speed is selected as the Load Balance Mode.
2. In DSL auto mode, the router will reboot automatically while switching between VDSL2 and ADSL lines.
3. Customer and service tag are used for different network environments. Customer tag is required for most ISPs while Service tag is required when ISP needs QinQ packets.

OK Cancel



Guida alla Configurazione connettività FUTURE (OF) su Draytek 2765/2865/2927

Compilare il form che vi si presenta in questo modo, ponendo attenzione ai campi in giallo, quindi, procedere inserendo il Ping Detect, infine procedere con OK e se viene chiesto il reboot non è necessario farlo nell'immediato ma lo faremo dopo;

3. Internet Access

Andare nella sezione WAN→Internet Access, e procedere aprendo il Details Page della WAN1;

Note:

- 1: (Optional) Required for some ISPs. Leave blank if in doubt because the connection request might be denied if "Service Name" is incorrect.
- 2: If this box is checked while using the PPPoA protocol, the router will behave like a modem which only serves the PPPoE client on the LAN.

OK

Cancel



Guida alla Configurazione connettività FUTURE (OF) su Draytek 2765/2865/2927

Compilare il form che vi si presenta in questo modo, ponendo sempre attenzione ai campi in giallo, quindi assicurarsi di essere nella sezione per la PPPoE e aver messo la spunta su Enable, impostare come username e password: openfiber, e settare correttamente Ping Detect e MTU con i valori in immagine, infine procedere dando l'OK e adesso procedere con il reboot del DrayTek.

Una volta settato il tutto attendere qualche minuto che la PPPoE salga correttamente, e la configurazione si può ritenere conclusa.