



Guida alla Configurazione della connettività FUTURE (VLAN 835) su Draytek 2962

1. Cablaggio connettività

Procedere in primis con il corretto cablaggio con WAN nella porta RJ45 del DrayTek e successivamente il cavo di alimentazione;

2. General Setup

Accedere al Draytek 2962 all'IP 192.168.1.1 con parametri username: admin; password: admin
(Procedere con il cambio password a seguito di primo accesso e prima configurazione)

Andare nella sezione WAN→General Setup, e procedere aprendo l'interfaccia della WAN1;

WAN >> General Setup

WAN 1

Note:

The line speed setting of WAN interface is available only when According to Line Speed is selected as the Load Balance Mode.

OK

Cancel



Guida alla Configurazione della connettività FUTURE (VLAN 835) su Draytek 2962

Compilare il form che vi si presenta in questo modo, ponendo attenzione ai campi in giallo, quindi, procedere inserendo il Ping Detect e impostando il VLAN TAG a 835, infine procedere con OK e se viene chiesto il reboot non è necessario farlo nell'immediato ma lo faremo dopo;

3. Internet Access

DrayTek Vigor 2962 Series

Off ☐ IP6 ☒

Dashboard
Wizards
Online Status

Search Menu

Port Setup
WAN
General Setup
Internet Access
Multi-VLAN
WAN Budget
LAN
Hotspot Web Portal
Routing
NAT
Firewall
User Management
Objects Setting
CSM
Bandwidth Management
Applications
VPN and Remote Access
Certificate Management
USB Application
System Maintenance
Diagnostics

WAN >> Internet Access

Internet Access

Index	Display Name	Physical Mode / Port	Access Mode	Details Page	IPv6
WAN1		Ethernet / P1	PPPoE		
WAN2		Ethernet / P2	Static or Dynamic IP		

DHCP Client Option

Andare nella sezione WAN→Internet Access, e procedere aprendo il Details Page della WAN1;

WAN >> Internet Access

WAN 1

PPPoE ☒ Enable ☐ Disable

Static or Dynamic IP

IPv6

ISP Access Setup

Username

Password

More Options

WAN Connection Detection

Mode

Primary Ping IP

Secondary Ping IP

☐ Ping Gateway IP

TTL

Ping Interval second(s)

Ping Retry times

MTU (Max:1492)

PPP/MP Setup

PPP Authentication

Idle Timeout second(s)

IP Assignment (IPCP) ☐ Static ☒ Dynamic

Fixed IP Address

WAN IP Alias

Dial-Out Schedule

Index(1-15) in Setup:

=>

=> =>

TTL

☒ Change the TTL value

☒ Default MAC Address

☐ Specify a MAC Address

: : : : :

OK Cancel

Note:

VPN feature may be affected when the value of MTU is changed, please also check your value of VPN MSS in [VPN and Remote Access >> PPP General Setup](#) or [VPN and Remote Access >> IPsec General Setup](#) page.

We recommend to put the same decreased value on VPN MSS. For example, reducing the MTU from 1500 -> 1400, then it will need to reduce 100 from MSS value.



Guida alla Configurazione della connettività FUTURE (VLAN 835) su Draytek 2962

Compilare il form che vi si presenta in questo modo, ponendo sempre attenzione ai campi in giallo; quindi, assicurarsi di essere nella sezione per la PPPoE e aver messo la spunta su Enable, impostare come username e password le credenziali inviate via mail, e settare correttamente Ping Detect e MTU con i valori in immagine, infine procedere dando l'OK e adesso procedere con il reboot del DrayTek.

Una volta settato il tutto attendere qualche minuto che la PPPoE salga correttamente, e la configurazione si può ritenere conclusa.